TAO-A Option Switch Settings: 1(Pulse/NISR/ICT/5V_Enable)

Supported bill MXP 20, 50, 100, 200
USD 1, 5, 10, 20 8bills.

TAO-A dip-switch settings and functions:

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
Reject MXP 20 & USD 1	ON											
★ Accept MXP 20 & USD 1	OFF											
Reject MXP 50 & USD 5		ON										
★ Accept MXP 50 & USD 5		OFF										
Reject MXP 100 & USD 10			ON									
★ Accept MXP 100 & USD 10			OFF									
Reject MXP 200 & USD 20				ON								
★ Accept MXP 200 & USD 20				OFF								
Accept Mexico Pesos and US Dollars (Note 1)					ON							
★ Accept Mexico Pesos Only (Note 1)					OFF							
Reserved						ON						
★ Reserved						OFF						
Harness Disable							ON					
★ Harness Enable							OFF					
Inhibit Active High								ON				
★ Inhibit Active Low								OFF				
★ 1 pulse / MXP 10									OFF	OFF		
2 pulses / MXP 10									ON	OFF		
5 pulses / MXP 10									OFF	ON		
10 pulses / MXP 10									ON	ON		
★ Interface Timing Conversion — 50ms on / 50ms off											OFF	OFF
Interface Timing Conversion — 60ms on / 300ms off											ON	OFF
Interface Timing Conversion — 30ms on / 50ms off											OFF	ON
Interface Timing Conversion — 150ms on / 150ms off											ON	ON

★ Manufacture setting

Note : (1) For Accepting US Dollars, make sure you have dip 5 set to ON position.
(* Exchange Rate on USD to MXP is 1:10)
(2) Reset the bill acceptor after setting the dip switch.
(3) SW7 and SW8 of the 8-switch DIP and the 4-switch DIP are for pulse protocol only.

Appendix

Interface Settings: 2(ICT)

INTERFACE	SW1	SW2	SW3	SW4
★ Reserved	ON			
Reserved	OFF			
★ ICT Mode		ON	ON	
NISR Mode		OFF	ON	
Pulse Mode		ON	OFF	
5V Enable Mode		OFF	OFF	
★ Reserved				ON
Reserved				OFF

★ Manufacture setting

Interface Settings: 2(NISR)

INTERFACE	SW1	SW2	SW3	SW4
★ Reserved	ON			
Reserved	OFF			
ICT Mode		ON	ON	
★ NISR Mode		OFF	ON	
Pulse Mode		ON	OFF	
5V Enable Mode		OFF	OFF	
★ Reserved				ON
Reserved				OFF

★ Manufacture setting

Interface Settings: 2(Pulse)

INTERFACE	SW1	SW2	SW3	SW4
★ Credit-Pulse Normal HIGH	ON			
Credit-Pulse Normal LOW	OFF			
ICT Mode		ON	ON	
NISR Mode		OFF	ON	
★ Pulse Mode		ON	OFF	
5V Enable Mode		OFF	OFF	
★ Reserved				ON
Reserved				OFF

★ Manufacture setting

Interface Settings: 2(5V_Enable)

INTERFACE	SW1	SW2	SW3	SW4
★ Credit-Pulse Normal HIGH	ON			
Credit-Pulse Normal LOW	OFF			
ICT Mode		ON	ON	
NISR Mode		OFF	ON	
Pulse Mode		ON	OFF	
★ 5V Enable Mode		OFF	OFF	
★ Reserved				ON
Reserved				OFF

★ Manufacture setting